

# PCI Express Multiport Serial Board Series Quick Installation Guide

---

**Version 2.1, December 2019**

## **Technical Support Contact Information** **[www.moxa.com/support](http://www.moxa.com/support)**

### Moxa Americas:

Toll-free: 1-888-669-2872

Tel: 1-714-528-6777

Fax: 1-714-528-6778

### Moxa China (Shanghai office):

Toll-free: 800-820-5036

Tel: +86-21-5258-9955

Fax: +86-21-5258-5505

### Moxa Europe:

Tel: +49-89-3 70 03 99-0

Fax: +49-89-3 70 03 99-99

### Moxa Asia-Pacific:

Tel: +886-2-8919-1230

Fax: +886-2-8919-1231

### Moxa India:

Tel: +91-80-4172-9088

Fax: +91-80-4132-1045

# MOXA®

© 2019Moxa Inc. All rights reserved.

**P/N: 1802001182042**



## Overview

Moxa's new PCI Express Multiport Serial Boards series is designed for POS and ATM applications and for use by industrial automation system manufacturers and system integrators.

## Package Checklist

Before installing the PCI Express board, verify that the package contains the following items:

- 1 MOXA multiport serial board (1 PCI Express board or 1 PCI Express-A Intelligent board)
- Low-profile bracket (low profile models only)
- Quick installation guide (printed)
- Warranty card

**NOTE** Notify your sales representative if any of the above items are missing or damaged.

## Hardware Installation Procedure

The PCI Express board **MUST** be plugged into the PC before the driver is installed.

Follow the steps below.

1. **Install the board.** Power off the PC and then plug the board firmly into any open PCI Express slot.
2. **Plug the connection cable into the board's connector.** (Refer to **Pin Assignments** for the cable pin assignment).
3. **Start system and verify the driver initialization.**

## Software Installation Information

1. **Get the driver at [www.moxa.com](http://www.moxa.com).** Base on the OS type, choosing the corresponding driver.
2. **Installing the driver:**
  - **For Windows OS** (Take the installation of Win7 as an example)
    - 2.1. Unzip and execute the .exe file
    - 2.2. Follow the instructions to install the drivers
  - **For Linux**  
Execute the following commands from the Linux prompt:
    - 2.1. Get the driver at [www.moxa.com](http://www.moxa.com) and unzip the file:

```
#cd /  
#mkdir moxa  
#cd moxa  
#cp /<driver  
directory>/driv_linux_smart_<version>_build_<build_date>  
.tgz.  
#tar -zxvf  
driv_linux_smart_<version>_build_<build_date>.tgz
```

      - 2.2. Install the driver:

```
#cd mxser  
#./mxinstall
```

- 2.3. Verify the driver status  
Use the Moxa diagnostic utility to verify the driver status:  
#cd /moxa/mxser/utility/diag  
#./msdiag
  - 2.4. Test the tty port  
Use the Moxa terminal utility to test the tty ports:  
#cd /moxa/mxser/utility/term  
#./msterm
3. **Intelligent RS-485** (If your multiport serial board is CP-102E/CP-102EL, CP-132EL/CP-132EL-I, or CP-114EL/CP-114EL-I, then your software installation is completed. On the other hand, if your multiport serial board is PCI Express-A, and with interface RS-485-2W, then you should follow this section to complete the intelligent RS-485 setting.)

- **For Windows OS**

- 3.1. Go to the device management to complete the model properties setting.
- 3.2. Click **Start Diagnosis**. (It should be RS-485-2W). If the status is **OK**, nothing further needs to be done. If the status is **Waveform Distortion, Data Error, or Receive Reflect Signal**, go to next step to do the auto tuning
- 3.3. Auto Tuning  
Still in the **Properties Settings** page, click on the COM number that shows the error message.  
Click **Auto Tuning**.  
Click **OK** to apply the setting adjustment for the Bias Resistor and Termination Resistor.

- **For Linux**

Follow these steps to configure the Intelligent RS-485 in Linux


- 3.1. Detect the configurations of the port by the following command:  
#./muestty -g /dev/ttyMUE1#cd /
- 3.2. Use the following command to run diagnosis to see if the setting is correct.  
#./muestty -d /dev/ttyMUE1
- 3.3. If the alarm status shows **OK**, nothing further needs to be done. If the alarm status shows **Fail**, then there are problems with the setting. Do the auto-tuning process with the following command  
#./muestty -a /dev/ttyMUE1
- 3.4. Manually configure the Pull Up/Down resistor and the terminator resistor with the assigned values:  
#./muestty -p (assigned value) /dev/ttyMUE1  
#./muestty -t (assigned value) /dev/ttyMUE1
- 3.5. Do the diagnosis again:  
#./muestty -d /dev/ttyMUE1

## Pin Assignments

### CP-102E / CP-102EL

#### Male DB9 (CBL-M25M9x2-50 for CP-102EL)


Pin	RS-232
1	DCD
2	RxD
3	TxD
4	DTR
5	GND
6	DSR
7	RTS
8	CTS



### CP-132EL/CP-132EL-I

#### Male DB9 (Device side)


Pin	RS-422/ RS-485-4W	RS-485-2W
1	TxD-(A)	-
2	TxD+(B)	-
3	RxD+(B)	Data+(B)
4	RxD-(A)	Data+(A)
5	GND	GND
6	-	-
7	-	-
8	-	-



### CP-114EL/CP-114EL-I


#### Male DB9 (CBL-M44M9x4-50)

Pin	RS-232	RS-422/ RS-485-4W	RS-485-2W
1	DCD	TxD-(A)	-
2	RxD	TxD+(B)	-
3	TxD	RxD+(B)	Data+(B)
4	DTR	RxD-(A)	Data+(A)
5	GND	GND	GND
6	DSR	-	-
7	RTS	-	-
8	DCD	-	-



#### Male DB25 (CBL-M44M25x4-50)


Pin	RS-232	RS-422/ RS-485-4W	RS-485-2W
2	TxD	RxD+(B)	Data+(B)
3	RxD	TxD+(B)	-
4	RTS	-	-
5	CTS	-	-
6	DSR	-	-
7	GND	GND	GND
8	DCD	TxD-(A)	-
20	DTR	RxD-(A)	Data-(A)



## CP-118E-A-I / CP-138E-A-I


### Male DB9 (CBL-M78M9x8-100)

Pin	RS-232	RS-422/ RS-485-4W	RS-485-2W
1	DCD	TxD-(A)	-
2	RxD	TxD+(B)	-
3	TxD	RxD+(B)	Data+(B)
4	DTR	RxD-(A)	Data-(A)
5	GND	GND	GND
6	DSR	-	-
7	RTS	-	-
8	CTS	-	-



### Male DB25 (CBL-M78M25x8-100)


Pin	RS-232	RS-422/ RS-485-4W	RS-485-2W
2	TxD	RxD+(B)	Data+(B)
3	RxD	TxD+(B)	-
4	RTS	-	-
5	CTS	-	-
6	DSR	-	-
7	GND	GND	GND
8	DCD	TxD-(A)	-
20	DTR	RxD-(A)	Data-(A)



## CP-134EL-A-I


### Male DB9 (CBL-M44M9x4-50)

Pin	RS-232	RS-422/ RS-485-4W	RS-485-2W
1	DCD	TxD-(A)	-
2	RxD	TxD+(B)	-
3	TxD	RxD+(B)	Data+(B)
4	DTR	RxD-(A)	Data-(A)
5	GND	GND	GND
6	DSR	-	-
7	RTS	-	-
8	CTS	-	-



### Male DB25 (CBL-M44M25x4-50)


Pin	RS-232	RS-422/ RS-485-4W	RS-485-2W
2	TxD	RxD+(B)	Data+(B)
3	RxD	TxD+(B)	-
4	RTS	-	-
5	CTS	-	-
6	DSR	-	-
7	GND	GND	GND
8	DCD	TxD-(A)	-
20	DTR	RxD-(A)	Data-(A)



## CP-116E-A


### Male DB9 (OPT8-M9+ / CBL-M68M9x8-100)

Pin	RS-232	RS-422/ RS-485-4W	RS-485-2W
1	DCD	TxD-(A)	-
2	RxD	TxD+(B)	-
3	TxD	RxD+(B)	Data+(B)
4	DTR	RxD-(A)	Data-(A)
5	GND	GND	GND
6	DSR	-	-
7	RTS	-	-
8	CTS	-	-



### Male DB25 (OPT8B+ / CBL-M68M25x8-100)

Pin	RS-232	RS-422/ RS-485-4W	RS-485-2W
2	TxD	RxD+(B)	Data+(B)
3	RxD	TxD+(B)	-
4	RTS	-	-
5	CTS	-	-
6	DSR	-	-
7	GND	GND	GND
8	DCD	TxD-(A)	-
20	DTR	RxD-(A)	Data-(A)



### Female DB25 (OPT8A+/S+)

Pin	RS-232	RS-422/ RS-485-4W	RS-485-2W
2	RxD	TxD+(B)	-
3	TxD	RxD+(B)	Data+(B)
4	CTS	-	-
5	RTS	-	-
6	DTR	RxD-(A)	Data-(A)
7	GND	GND	GND
8	DCD	TxD-(A)	-
20	DSR	-	-

