

TSN-G5016 Series Quick Installation Guide

Moxa Industrial Managed Ethernet Switch

Version 1.0, December 2025

Technical Support Contact Information
www.moxa.com/support

MOXA[®]

© 2025 Moxa Inc. All rights reserved.

P/N: 1802050160010



Package Checklist


The TSN-G5016 Series is shipped with the following items. If any of these items are missing or damaged, please contact your customer service representative for assistance.

- 1 TSN-G5016 Series industrial Ethernet switch
- 1 RJ45 to RS-232 9-pin female console cable
- 1 Quick installation guide (printed)
- 1 Warranty card
- 2 Terminal blocks

Default Settings

- Default IP address: 192.168.127.253
- Default Subnet Mask: 255.255.255.0
- Default Username: admin
- Default Password: moxa


TSN-G5016 Series Panel Layout



1. USB storage port (Type A)
2. 12 x 10/100/1000BaseT(X) RJ45 Ethernet ports
3. LED indicators (STATE, FAULT, PWR1, PWR2, M/N, C/I, SYNC, R1, R2, R3)
4. LED indicator for 1000BaseT(X)
5. LED indicator for 10/100BaseT(X)
6. 4 x SFP ports
TSN-G5016-4GS models: 100/1000BaseSFP
TSN-G5016-4XGS models: 10GBaseSFP
7. Console port (RJ45)
8. Rubber cover for reset button and microSD card slot (currently disabled)
9. Grounding screw (chassis ground)
10. Relay output (terminal block)
11. 2 x power inputs (terminal block)
12. Digital input (terminal block)
13. DIN-rail mounting kit
14. Model side label

Dimensions

Unit: mm (inch)




DIN-rail Mounting

When shipped, the metal DIN-rail mounting kit is fixed to the back panel of the TSN-G5016 Series. Mount the TSN-G5016 Series on the corrosion-free mounting rail that adheres to the EN 60715 standard.

Suggested Installation Method

Step 1—Insert the upper lip of the DIN-rail kit into the mounting rail.

Step 2—Press the TSN-G5016 Series towards the mounting rail until it snaps into place.




Suggested Removal Method

Step 1—Pull down the latch on the DIN-rail kit with a screwdriver.

Steps 2—Slightly pull the TSN-G5016 Series forward.


Steps 3—Lift the TSN-G5016 Series up to remove it from the mounting rail.




Wall-mounting

For some applications, you will find it convenient to mount your TSN-G5016 Series on the wall, as illustrated below.

Step 1—Remove the aluminum DIN-rail attachment plate from the TSN-G5016 Series rear panel, and then attach the wall mount plates, as shown in the diagram below.



Step 2—Mounting the TSN-G5016 Series on the wall requires four screws. Use the switch, with wall mount plates attached, as a guide to mark the correct locations of the four screws. The heads of the screws should be 3.5 to 6.0 mm in diameter, and the shafts should be 2.5 to 3.5 mm in diameter, as shown in the figure at the right.




The length of the screws should be at least 10 mm.

NOTE Before tightening the screws into the wall, make sure the screw head and shank size are suitable by inserting the screw into one of the keyhole-shaped apertures of the wall mounting plates.

Do not screw the screws in all the way—leave about 2 mm to allow room for sliding the wall mount panel between the wall and the screws.

Step 3—Once the screws are fixed in the wall, insert the four screw heads through the large parts of the keyhole-shaped apertures, and then slide the TSN-G5016 Series downwards, as indicated on the right. Tighten the four screws for added stability.



ATTENTION

Safety First!

External metal parts are hot. Take necessary precautions if it is necessary to touch.



ATTENTION

In order to ensure reliable operations, please make sure the operating temperature of the environment does not exceed the specifications. When mounting the TSN-G5016 Series with other operating units in a cabinet without forced ventilation, a minimum of 5 cm space on both the left and right of the switch is recommended.

Wiring Requirements



ATTENTION

Safety First!

Be sure to disconnect the power cord before installing and/or wiring your Moxa TSN-G5016 Series. Calculate the maximum possible current in each power wire and common wire. Observe all electrical codes dictating the maximum current allowable for each wire size. If the current goes above the maximum ratings, the wiring could overheat, causing serious damage to your equipment.




ATTENTION

We suggest using a copper conductor with the cable type - AWG (American Wire Gauge) 18-24 and the corresponding pin type cable terminals. In addition, the wire must be able to withstand at least 105°C.

NOTE We suggest the length of the pin type cable terminal is 8 mm.

In order to tighten the wire properly, please perform the following three steps: Step 1. Use a small flathead screwdriver to press the push-in button beside each terminal of the terminal block connector. Step 2. Insert the wire. Step 3. Release the screwdriver after the wire has been fully inserted. Please refer to the diagram below.



Wiring the Relay Contact


The TSN-G5016 Series has one relay output for identifying when a specific event has occurred (i.e., fault; see below). This relay output uses the first contact out of the first 2-pin terminal on the TSN-G5016 Series' top panel.

Refer to the instructions and diagram below on how to connect the wires to the terminal block connector, and how to attach the terminal block connector to the terminal block receptor.


Step 1—Insert two wires into the relay position (see the diagram below showing the top view) on the terminal to form an open circuit.

Step 2—To keep the relay wires from coming loose, use a small flathead screwdriver to press the button beside each terminal of the plastic terminal block connector in order to insert the wire tightly. Release the screwdriver after the wire has been inserted properly.

Step 3—Insert the plastic terminal block connector prongs into the terminal block receptor, which is located on the TSN-G5016 Series' top panel. Finally, tighten the screws either side of the terminal block and ensure that the terminal block is fixed tightly on to the device.




NOTE The relay output of the TSN-G5016 Series reflects a potential-free, normally opened electromagnetic relays. When there is no power supply to the switch, or user-configured events are triggered, the relays will open. To indicate a fault has occurred one can integrate the relay contact on the TSN-G5016 Series with an external alarming system circuit so that the status of user-configured events or no power supply can be monitored. An example is given in the diagram below where the buzzer will sound when user-configured events happen.



Wiring the Digital Input

The TSN-G5016 Series has one set of digital inputs (DI). The DI consists of two contacts of the second 4-pin terminal block on the TSN-G5016 Series' top panel, and the other 2 contacts are used for the power input 2 (PWR 2/P2).

Refer to the instructions and diagram (top view) below on how to connect the wires to the terminal block connector, and how to attach the terminal block connector to the terminal block receptor.



Step 1—Insert the negative (ground)/positive DI wires into the respective \perp /I terminals.


Step 2—To prevent the DI wires from coming loose, use a small flathead screwdriver to press the button beside each terminal of the plastic terminal block connector in order to insert the wire tightly. Release the screwdriver after the wire has been properly inserted.

Step 3—Insert the plastic terminal block connector prongs into the terminal block receptor, which is located on the top panel of the TSN-G5016 Series. Finally, tighten the screws either side of the terminal block and ensure that the terminal block is fixed tightly on to the device.

Wiring the Redundant Power Inputs (12-48 VDC)

NOTE The devices are designed for operation with a Safety Extra-Low Voltage. Thus, they may only be connected to the supply voltage connections and to the signal contact with the Safety Extra-Low Voltages (SELV).

The TSN-G5016 Series has two sets of power inputs—power input 1 (PWR 1/P1) and power input 2 (PWR 2/P2). The top view of the terminal block connector and the positions of the power inputs are shown below.



Take the following steps to wire the redundant power inputs:

Step 1—Insert the Positive/Negative DC wires into the V+/V- terminals for PWR 1 and PWR 2.

Step 2—To prevent the DC wires from coming loose, use a small flathead screwdriver to press the button beside each terminal of the plastic terminal block connector in order to insert the wire tightly. Release the screwdriver after the wire has been properly inserted.

Step 3—Insert the plastic terminal block connector prongs into the terminal block receptor, which is located on the top panel of the TSN-G5016 Series. Finally, tighten the screws either side of the terminal block and ensure that the terminal block is fixed tightly on to the device.



ATTENTION

Before connecting the TSN-G5016 Series to the DC power inputs, ensure the DC power supply voltage is stable and of a correct level and polarity.

Communication Connections

Each TSN-G5016 Series Ethernet switch has various types of communication ports:

- 1 RJ45 console port (RS-232 interface)
- 1 USB storage port (type A connector)
- 12 10/100/1000BaseT(X) Ethernet ports
- 4 1000Base SFP slots (TSN-G5016-4GS-SoMD-LV-T)
- 4 10GBase SFP slots (TSN-G5016-4XGS-SoMD-LV-T)
- 1 microSD card slot (currently disabled)


Console Port Connection

The TSN-G5016 Series has one RJ45 console port (RS-232 interface), located on the front panel. Use an RJ45-to-DB9 (see the cable following wiring diagrams) to connect the TSN-G5016's console port to your PC's

COM port. You may then use a console terminal program, such as Moxa PComm Terminal Emulator, to access the TSN-G5016 that has a baud rate of 115200.

RJ45 Console Port Pinouts

Pin	Description
1	DSR
2	RTS
3	-
4	TxD
5	RxD
6	GND
7	CTS
8	DTR



USB Connection

This interface is reserved for future use.

10/100/1000BaseT(X) Ethernet Port Connection

The 10/100/1000BaseT(X) ports located on Moxa TSN-G5016 Switch's front panel are used to connect to Ethernet-enabled devices. Most users will choose to configure these ports for Auto MDI/MDI-X mode, in which case the port's pinouts are adjusted automatically depending on the type of Ethernet cable used (straight-through or cross-over), and the type of device (NIC-type or HUB/Switch-type) connected to the port.

In the following section, we give pinouts for both MDI (NIC-type) ports and MDI-X (HUB/Switch-type) ports. We also give cable wiring diagrams for straight-through and cross-over Ethernet cables.

10/100Base T(X) RJ45 Pinouts


MDI Port Pinouts

Pin	Signal
1	Tx+
2	Tx-
3	Rx+
6	Rx-

MDI-X Port Pinouts


Pin	Signal
1	Rx+
2	Rx-
3	Tx+
6	Tx-

8-pin RJ45




1000Base T(X) RJ45 Pinouts


Pin	MDI	MDI-X
1	BI_DA+	BI_DB+
2	BI_DA-	BI_DB-
3	BI_DB+	BI_DA+
4	BI_DC+	BI_DD+
5	BI_DC-	BI_DD-
6	BI_DB-	BI_DA-
7	BI_DD+	BI_DC+
8	BI_DD-	BI_DC-



RJ45 (8-pin) to RJ45 (8-pin) Straight-through Cable Wiring



RJ45 (8-pin) to RJ45 (8-pin) Cross-over Cable Wiring




1000/10GBase-X Fiber Port

The fiber ports on the TSN-G5016 Series are SFP type slots, which support 1000BaseSFP (TSN-G5016-4GS models) or 10GBaseSFP (TSN-G5016-4XGS models). Moxa provides a broad range of transceiver models for various distance requirements.


The concept behind the LC port and cable is quite straightforward. Suppose you are connecting devices I and II. Unlike electrical signals, optical signals do not require a circuit in order to transmit data. Consequently, one of the optical lines is used to transmit data from device I to device II, and the other optical line is used to transmit data from device II to device I, for full-duplex transmission.

Remember to connect the Tx (transmit) port of device I to the Rx (receive) port of device II, and the Rx (receive) port of device I to the Tx (transmit) port of device II. If you make your own cable, we suggest labeling the two sides of the same line with the same letter (A-to-A and B-to-B, as shown below, or A1-to-A2 and B1-to-B2).

LC-port Pinouts



LC-port to LC-port Cable Wiring




ATTENTION

This is a Class 1 Laser/LED product. To avoid causing serious damage to your eyes, do not stare directly into the Laser Beam.

Installing the microSD card

NOTE The microSD card function is currently disabled.

The TSN-G5016 Series has a microSD slot located on the top panel of the switch. Remove the rubber cover first.



Insert the microSD card into the slot. Make sure you insert the card in the correct direction. There is an image above the slot indicating the direction that the microSD card should be inserted.



Reset Button

The reset button can perform two functions. One is to reset the switch to factory default settings and the other is to reboot the switch if the button has been pressed and released immediately. This button is located inside the rubber cover on the top panel of the switch.

Reset to Factory Default Settings

Use a pointed object, such as a straightened paper clip or needle, to press the reset button for five seconds to load the factory default settings. When you start pressing the reset button, the STATE LED will

start to blink about one time per second. After five seconds, you can release the reset button to load factory default settings.

NOTE DO NOT power off the switch when loading the default settings.

LED Indicators

LED	Color	Status	Description
System LEDs			
PWR1	Green	On	System is running normally.
		Blinking	1. The system is booting up. 2. When pressing the reset button for 5 seconds to reset to factory default settings.
	Red	On	System failed to initialize.
PWR 1	Amber	On	Power is being supplied to the main system's power input PWR1.
		Off	Power is not being supplied to the main system's power input PWR1.
PWR 2	Amber	On	Power is being supplied to the main system's power input PWR2.
		Off	Power is not being supplied to the main system's power input PWR2.
FAULT	Red	On	Reserved.
		Off	The system is operating normally.
MSRT/HEAD	Green	On	Reserved for future use.
		Off	Reserved for future use.
CPLR/TAIL	Green	On	Reserved for future use.
		Off	Reserved for future use.
SYNC	Amber	On	The PTP function is enabled.
		Blinking (4 Hz)	The switch is receiving sync packets while the time is not converged yet.
		Off	The PTP function is disabled.
	Green	On	The PTP function successfully converged.
		Off	The PTP function is disabled.
R1	Green	On	Reserved for future use.
		Off	Reserved for future use.
R2	Green	On	Reserved for future use.
		Off	Reserved for future use.
R3	Green	On	Reserved for future use.
		Off	Reserved for future use.
Port LEDs			
Copper (10/100/1000 Mbps)	Green	On	When the port is active and linking at 1000 Mbps.
		Blinking	When the data is being transmitted at 1000 Mbps.
		Off	When the port is inactive or the link is down.
	Amber	On	When the port is active and linking at 10/100 Mbps.

LED	Color	Status	Description
		Blinking	When the data is being transmitted at 10/100 Mbps.
		Off	When the port is inactive or the link is down.
SFP+ (1GbE/10GbE)	Green	On	When the port is active and linking at the highest supported speed (1GbE or 10GbE).
		Blinking	When the data is being transmitted at the highest supported speed (1GbE or 10GbE).
		Off	When the port is inactive or the link is down.

Specifications

Interface	
RJ45 Ports	10/100/1000BaseT(X)
Fiber Ports	TSN-G5016-4GS: 1000BaseSFP TSN-G5016-4XGS: 10GBaseSFP
Console Port	RS-232 (RJ45)
Relay Contact (Relay Output)	1 normally open electromagnetic relays output with current carrying capacity of 1 A @ 24 VDC
Digital Input	1 isolated digital input: <ul style="list-style-type: none"> +13 to +30 V for state "1" -30 to +3 V for state "0" Max. input current: 8 mA
Button	Reset button
Power Requirements	
Rated Input Voltage	12 to 48 VDC, redundant dual inputs
Input Current	3 A (max.)
Connection	2 removable 4-contact terminal blocks
Overload Current Protection	Supported
Reverse Polarity Protection	Supported
Physical Characteristics	
Housing	Metal
IP Rating	IP40
Dimension (W x H x D)	84 x 140 x 105 mm (3.31 x 5.51 x 4.13 in)
Weight	1,380.5 g (3.04 lb)
Installation	DIN-rail mounting, wall mounting (with optional kit)
Environmental Limits	
Operating Temperature	-40 to 70°C (-40 to 158°F)
Storage Temperature	-40 to 85°C (-40 to 185°F)
Ambient Relative Humidity	5% to 95% (non-condensing)
Altitude	Up to 2000 m Note: Please contact Moxa if you require products guaranteed to function properly at higher altitude.
Standards and Certifications	
Safety	UL 61010-2-201, EN 62368-1

EMC	EN 55035/55032
EMI	CISPR 32, FCC Part 15B Class A
EMS	IEC 61000-4-2 ESD: Contact: 6 kV; Air: 8 kV IEC 61000-4-3 RS: 80 MHz to 1 GHz: 10 V/m IEC 61000-4-4 EFT: Power: 2 kV; Signal: 1 kV IEC 61000-4-5 Surge: Power: 2 kV; Signal: 1 kV IEC 61000-4-6 CS: Signal: 10 V IEC 61000-4-8 PFMF: 100 A/m, 60 s
Shock	IEC 60068-2-27
Freefall	IEC 60068-2-32
Vibration	IEC 60068-2-6
Note: Please check Moxa's website for the latest certification status.	
Warranty	
Warranty Period	5-years
Details	See www.moxa.com/warranty



ATTENTION

This device complies with Part 15 of the FCC rules.

Operation is subject to the following conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received including interference that may cause undesired operation.



ATTENTION

This product is for indoor use and meets the Pollution degree 2 requirements.

If the device needs to be cleaned it should be wiped with a dry cloth. The device must be installed within a suitable, secure, final enclosure. If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.