

# **MGate 5135/5435 Series User Manual**

---

**Version 1.0, September 2022**

[www.moxa.com/products](http://www.moxa.com/products)

**MOXA<sup>®</sup>**

© 2022 Moxa Inc. All rights reserved.

# **MGate 5135/5435 Series User Manual**

The software described in this manual is furnished under a license agreement and may be used only in accordance with the terms of that agreement.

## **Copyright Notice**

© 2022 Moxa Inc. All rights reserved.

## **Trademarks**

The MOXA logo is a registered trademark of Moxa Inc.  
All other trademarks or registered marks in this manual belong to their respective manufacturers.

## **Disclaimer**

- Information in this document is subject to change without notice and does not represent a commitment on the part of Moxa.
- Moxa provides this document as is, without warranty of any kind, either expressed or implied, including, but not limited to, its particular purpose. Moxa reserves the right to make improvements and/or changes to this manual, or to the products and/or the programs described in this manual, at any time.
- Information provided in this manual is intended to be accurate and reliable. However, Moxa assumes no responsibility for its use, or for any infringements on the rights of third parties that may result from its use.
- This product might include unintentional technical or typographical errors. Changes are periodically made to the information herein to correct such errors, and these changes are incorporated into new editions of the publication.

## **Technical Support Contact Information**

[www.moxa.com/support](http://www.moxa.com/support)

# Table of Contents

<b>1. Introduction</b>	<b>4</b>
<b>2. Getting Started</b>	<b>5</b>
Connecting the Power	5
Connecting Serial Devices	5
Connecting to a Network	5
Installing DSU Software	5
Log In to the Web Console	6
microSD	6
<b>3. Web Console Configuration and Troubleshooting</b>	<b>8</b>
System Overview Dashboard	8
System Settings	9
System Settings—General Settings	9
System Settings—Network Settings	11
System Settings—Serial Settings	12
System Settings—SNMP Settings	14
Protocol Settings	17
Protocol Settings—Modbus Client Settings	17
Protocol Settings—EtherNet/IP Adapter Settings	24
Diagnostics	27
Diagnostics—Protocol Diagnostics	27
Diagnostics—Protocol Traffic	29
Diagnostics—Event Log	29
Diagnostics—Tag View	33
Diagnostics—Network Connections	34
Diagnostics—Ping	34
Diagnostics—LLDP	35
Security	36
Security—Account Management	36
Security—Service	39
Security—Allow List	40
Security—DoS Defense	41
Security—Login Policy	42
Security—Certificate Management	43
Maintenance	44
Maintenance—Configuration Import/Export	44
Maintenance—Firmware Upgrade	44
Maintenance—Load Factory Default	45
Restart	45
Status Monitoring	46
<b>4. Network Management Tool (MXstudio)</b>	<b>47</b>
<b>A. SNMP Agents with MIB II and RS-232-Like Groups</b>	<b>48</b>
RFC1213 MIB-II Supported SNMP Variables	48
RFC1317 RS-232-Like Groups	49

# 1. Introduction

---

The MGate 5135/5435 gateways are 1- and 4-port industrial Ethernet gateways, respectively for Modbus RTU/ASCII/TCP and EtherNet/IP network communications. To integrate existing Modbus devices onto an EtherNet/IP network, use the MGate 5135/5435 gateway as a Modbus client to collect data and exchange data with EtherNet/IP host. All models are protected by a rugged and compact metal housing, are DIN-rail mountable, and offer built-in serial isolation. The rugged design is suitable for industrial applications such as factory automation, power, oil and gas, water and wastewater, and other process automation industries.

## 2. Getting Started

---

### Connecting the Power

The unit can be powered by connecting a power source to the terminal block:

1. Loosen or remove the screws on the terminal block.
2. Turn off the power source and then connect a 12–48 VDC power line to the terminal block.
3. Tighten the connections, using the screws on the terminal block.
4. Turn on the power source.

Note that the unit does not have an on/off switch. It automatically turns on when it receives power. The PWR LED on the top panel will glow to show that the unit is receiving power. For power terminal block pin assignments, refer to the *Quick Installation Guide*, **Power Input and Relay Output Pinout** section.

### Connecting Serial Devices

The MGate supports Modbus serial devices. Before connecting or removing the serial connection, first make sure the power is turned off. For the serial port pin assignments, refer to the *Quick Installation Guide*, **Pin Assignments** section.

### Connecting to a Network

Connect one end of the Ethernet cable to the MGate's 10/100M Ethernet port and the other end of the cable to the Ethernet network. The MGate will show a valid connection to the Ethernet in the following ways:

- The Ethernet LED maintains a solid green color when connected to a 100 Mbps Ethernet network.
- The Ethernet LED maintains a solid orange color when connected to a 10 Mbps Ethernet network.
- The Ethernet LED will flash when Ethernet packets are being transmitted or received.

### Installing DSU Software


If you do not know the MGate gateway's IP address when setting it up for the first time (default IP is *192.168.127.254*); use an Ethernet cable to connect the host PC and MGate gateway directly. If you connect the gateway and host PC through the same Ethernet switch, make sure there is no router between them. You can then use the **Device Search Utility (DSU)** to detect the MGate gateways on your network. You can download DSU (Device Search Utility) from Moxa's website: [www.moxa.com](http://www.moxa.com).

The following instructions explain how to install the DSU, a utility to search for MGate units on a network.

1. Locate and run the following setup program to begin the installation process:  
**dsu\_setup\_[Version]\_Build\_[DateTime].exe**  
This version might be named **dsu\_setup\_Ver2.x\_Build\_xxxxxxxx.exe**
2. The Welcome window will greet you. Click **Next** to continue.
3. When the **Select Destination Location** window appears, click **Next** to continue. You may change the destination directory by first clicking on **Browse...**
4. When the **Select Additional Tasks** window appears, click **Next** to continue. You may select **Create a desktop icon** if you would like a shortcut to the DSU on your desktop.
5. Click **Install** to copy the software files.
6. A progress bar will appear. The procedure should take only a few seconds to complete.
7. A message will show the DSU has been successfully installed. You may choose to run it immediately by selecting **Launch DSU**.

8. You may also open the DSU through **Start > Programs > MOXA > DSU**.

The DSU window should appear as shown below. Click **Search** and a new Search window will pop up.




No	Model	LAN1 MAC Address	LAN1 IP Address	LAN2 MAC Address	LAN2 IP Address	Status	Firmware Version	Server Name
1	MGate 5435	00:90:E8:11:23:00	10.123.20.50	---			*****	MGate 5435_00000...
2	MGate 5135	00:90:E8:51:35:31	10.123.20.54	---			*****	MGate 5135_00000...

## Log In to the Web Console

Use the Web console to configure the MGate through Ethernet or verify the MGate's status. Use a web browser, such as Google Chrome to connect to the MGate, using the HTTPS protocol.

When the MGate gateway appears on the DSU device list, select the gateway and right-click the mouse button to open a web console to configure the gateway.

On the login page, create an account name and set a password when you log in for the first time. Or if you have already an account, log in with your account name and password.



MOXA

Log in to  
MGate 5135\_1234567

Info:  
Hello

Account Name  
\_\_\_\_\_

Password  
\_\_\_\_\_

LOG IN

## microSD

The MGate provides users with an easy way to back up, copy, replace, or deploy. The MGate is equipped with a microSD card slot. Users can plug in a microSD card to back up data, including the system configuration settings.

### First time use of a new microSD card with the MGate gateway

1. Format the microSD card as FAT file system through a PC.
2. Power off the MGate and insert the microSD card (ensure that the microSD card is empty).
3. Power on the MGate. The default settings will be copied to the microSD card.
4. Manually configure the MGate via web console, and all the stored changes will copy to the microSD card for synchronization.

### First time use of a microSD card containing a configuration file with the MGate gateway

1. Power off the MGate and insert the microSD card.
2. Power on the MGate.
3. The configuration file stored in the microSD card will automatically copy to the MGate.

### **Duplicating current configurations to another MGate gateway**

1. Power off the MGate and insert a new microSD card.
2. Power on the MGate.
3. The configuration will be copied from the MGate to the microSD card.
4. Power off the MGate and insert the microSD card to the other MGate.
5. Power on the second MGate.
6. The configuration file stored in the microSD card will automatically copy to the MGate.

### **Malfunctioning MGate replacement**

1. Replace the malfunctioning MGate with a new MGate.
2. Insert the microSD card into the new MGate.
3. Power on the MGate.
4. The configuration file stored on the microSD card will automatically copy to the MGate.

### **microSD card writing failure**

The following circumstances may cause the microSD card to experience a writing failure:

1. The microSD card has less than 20 Mbytes of free space remaining.
2. The microSD card is write-protected.
3. The file system is corrupted.
4. The microSD card is damaged.

The MGate will stop working in case of the above events, accompanied by a flashing Ready LED and beeping alarm. When you replace the MGate gateway's microSD card, the microSD card will synchronize the configurations stored on the MGate gateway. Note that the replacement microSD card should not contain any configuration files on it; otherwise, the out-of-date configuration will copy to the MGate device.

# 3. Web Console Configuration and Troubleshooting

This chapter provides a quick overview of how to configure the MGate 5135/5435 by web console.

## System Dashboard

This page gives a system dashboard of the MGate 5135/5435 gateway.

The screenshot displays the System Dashboard for an MGate 5435 gateway. The interface includes a sidebar with navigation options like System Settings, Protocol Settings, Diagnostic, and Security. The main content area is divided into several sections:

- System Information:** Shows a photo of the MGate 5435 device and its specifications: Model Name (MGate 5435), Serial No. (MOXA1234567), Firmware version (1.0.0 Build 22090811), Uptime (4 days 04h:19m:16s), IPv4 (10.123.4.44), MAC address (00:90:E8:36:78:43), and MicroSD (Not detected).
- Panel Status:** Displays the status of System LED (PWR1, PWR2, READY) and Port LED (ETH1, ETH2, EIP, MB).
- Event Summary:** A table showing recent events with columns for ID, Severity, Message, and Timestamp. It includes counts for Alert (49), Warning (29), and Info (47).
- Relay State:** A table listing events such as Power input failure and Ethernet link down, along with their states and Acknowledge buttons.

You can change your password or log out using the options on the top-right corner of the page.

The screenshot shows a user profile dropdown menu. The user is identified as 'Administrator admin'. Below the name, there are two buttons: 'Change Password' and 'Log Out'.

# System Settings

## System Settings—General Settings

On this page, you can change the name of the device and time settings.

General Setting  
Home > General Setting

System Time

Host Name  
MGate 5135\_1234567

Description

SAVE

### System Settings

Parameter	Value	Description
Host Name	Alphanumeric string	Enter a name that can help you uniquely identify the device. For example, you can include the name and function of the device.
Description	Alphanumeric string	(optional) You can include additional description about the device such as function and location.

### Time Settings

The MGate has a built-in real-time clock for time-calibration functions. Functions such as logs use the real-time clock to add the timestamp to messages.



### ATTENTION

First-time users should select the time zone first. The console will display the actual time in your time zone relative to the GMT. If you would like to change the real-time clock, select Local time. MGate's firmware will change the GMT time according to the Time Zone setting.

## General Setting

Home > General Setting

System **Time**

Current date and time: July 4, 2022 at 18:29:23

Timezone  
(GMT+08:00)Taipei

Daylight saving time  
 Enable  Disabled

Start

Month: 3 Week: 5 Day: 0 Hour: 1

End

Month: 10 Week: 5 Day: 0 Hour: 1

Offset  
+00:00

Sync Mode  
 Manual  Auto

[sync with browser](#)

Date  
2022/07/04

Hour: 18 Minute: 28 Second: 19

**SAVE**

Parameter	Value	Description
<b>Time zone</b>	User-selectable time zone	Shows the current time zone selected and allows change to a different time zone.
<b>Daylight saving time</b>	Enable Disable	Enables daylight saving time to automatically adjust the time according to the region.
<b>Sync Mode</b>	Manual	Use this setting to manually adjust the time (1900/1/1-2037/12/31) or sync with the browser time
	Auto	Specify the IP or domain of the time server to sync with (E.g., 192.168.1.1 or time.stdtime.gov.tw). This optional field specifies the IP address or domain name of the time server on your network. The module supports SNTP (RFC-1769) for automatic time calibration. The MGate will request the time information from the specified time server per the set configured time.

## System Settings—Network Settings

You can change the IP Configuration, IP Address, Netmask, Default Gateway, and DNS settings on the **Network Settings** page.

### Network Setting

Home > Network Setting

LAN Mode  
Switch ▼

---

#### LAN 1 IP Configuration

DHCP  Static

IP Address  
10.123.4.44

Netmask  
255.255.255.0

Gateway  
10.123.4.1

---

#### DNS Server

Preferred DNS Server  
10.168.1.23

Alternative DNS Server  
10.168.1.24

SAVE

Parameter	Value	Description
<b>LAN Mode</b>	<b>Switch, Dual IP, Redundant LAN</b>	The <b>Switch</b> mode allows users to install the device with daisy-chain topology. The <b>Dual IP</b> mode allows the gateway to have two different IP addresses, each with distinct netmask and gateway settings. The IP addresses can have the same MAC address. The <b>Redundant LAN</b> mode allows users to use the same IP address on both Ethernet ports. The default active LAN port is ETH1 after bootup. If the active LAN link is down, the device will automatically switch to the backup LAN ETH2.
<b>IP Configuration</b>	<b>DHCP, Static IP</b>	Select <b>Static IP</b> if you are using a fixed IP address. Select the DHCP option if you want the IP address to be dynamically assigned.
<b>IP Address</b>	192.168.127.254 (or other 32-bit number)	The <b>IP Address</b> identifies the server on the TCP/IP network.

Parameter	Value	Description
<b>Netmask</b>	255.255.255.0 (or other 32-bit number)	Identifies the server as belonging to a Class A, B, or C network.
<b>Gateway</b>	0.0.0.0 (or other 32-bit number)	The IP address of the router that provides network access outside the server's LAN.
<b>Preferred DNS Server</b>	0.0.0.0 (or other 32-bit number)	The IP address of the primary domain name server.
<b>Alternative DNS Server</b>	0.0.0.0 (or other 32-bit number)	The IP address of the secondary domain name server.

## System Settings—Serial Settings

The serial interface supports RS-232, RS-422, and RS-485 interfaces. You must configure the baudrate, parity, data bits, and stop bits before using the serial interface for the Modbus RTU/ASCII protocol. Incorrect settings will cause communication failures.

Serial Setting				
Home > Serial Setting				
Port	Interface	Baud Rate	Parity, Data Bits, Stop Bits	Flow Control
#1 AAAAA	RS-232	115200	Even, 8, 1	None

< # 1

Home > Serial Setting > # 1

Alias

---

Interface  
RS-485 2-wire ▼

---

Terminator  
 120Ω  None

Pull-up & Pull-down Resistor  
 1kΩ  150kΩ

Baud Rate  
38400 ▼

Parity  
None ▼

Data Bits  
 5  6  7  8

Stop Bits  
 1  2

FIFO  
 Enable  Disabled

Parameter	Value	Description
<b>Interface</b>	<b>RS-232, RS-422, RS-485 2-wire, RS-485 4-wire</b>	
<b>Baudrate</b>	300 bps to 921600 bps	
<b>Parity</b>	<b>None, Odd, Even, Mark, Space</b>	
<b>Data Bits</b>	<b>7, 8</b>	
<b>Stop Bits</b>	<b>1, 2</b>	
<b>FIFO</b>	<b>Enable, Disable</b>	The internal buffer of UART. Disabling FIFO can reduce the latency time when receiving data from serial communications, but this will also slow down the throughput.

Flow Control  
RTS toggle ▼

RTS on delay  
0

RTS off delay  
0

Parameter	Value	Description
<b>Flow Control</b> (only for RS-232 mode)	<b>None, RTS/CTS, RTS Toggle</b>	The RTS Toggle will turn off RTS signal when there is no data to be sent. If there is data to be sent, the RTS toggle will turn on the RTS signal before a data transmission and off after the transmission is completed.

Parameter	Value	Description
<b>RTS on delay</b>	0 to 100 ms	Only available for the RS-232 mode to implement the RTS Toggle function.
<b>RTS off delay</b>	0 to 100 ms	Only available for the RS-232 mode to implement the RTS Toggle function.

### RTS Toggle

The RTS Toggle function is available only in the **RS-232** mode. This flow-control mechanism is achieved by toggling the RTS pin in the transmission direction through a software setting. Data is transmitted after the RTS pin is toggled ON for the specified time interval. After the data transmission is finished, the RTS pin will toggle OFF for the specified time interval automatically.

## System Settings—SNMP Settings

### System Settings—SNMP Settings—SNMP Agent

#### SNMP Agent

Home > SNMP Agent

General    SNMPv3 Account    SNMPv3 Account Protection

**Status**

Enable     Disabled

Note: enable/disable this service through [Service Enablement](#)

**Version**

v1 v2c v3 ▼

**Contact**

\_\_\_\_\_

**Location**

\_\_\_\_\_

**Read Only Community**

\_\_\_\_\_

**Read/Write Community**

\_\_\_\_\_

[SAVE](#)

Parameters	Description
<b>Version</b>	The SNMP version; MGate supports SNMP V1, V2c, and V3.
<b>Contact</b>	The optional contact information; usually includes an emergency contact name and telephone number.
<b>Read Only Community</b>	A text password mechanism that is used to weakly authenticate queries to agents of managed network devices.
<b>Read/Write Community</b>	A text password mechanism that is used to weakly authenticate changes to agents of managed network devices.

## Read-only and Read/write Access Control

You can define usernames, passwords, and authentication parameters in SNMP for two levels of access control: read-only and read/write. The access level is indicated in the value of the Authority field. For example, Read-only authentication mode allows you to configure the authentication mode for read-only access, whereas Read/Write authentication mode allows you to configure the authentication mode for read/write access. For each level of access, you may configure the following:

SNMP Agent

Home > SNMP Agent

General **SNMPv3 Account** SNMPv3 Account Protection

+ CREATE  
maximum number of account is 2

Account Name	Authority	Authentication Type	Privacy Type	
center	Read/Write	SHA1	Disable	 

### Create SNMPv3 Account

Account Name

---

Authority

Read Only



Authentication Type

Disable



CANCEL

SAVE

Parameters	Value	Description
<b>Account Name</b>		The username for which the access level is being defined.
<b>Authority</b>	<b>Read Only</b> <b>Read/Write</b>	The level of access allowed
<b>Authentication Type</b>	<b>Disable</b> <b>MD5</b> <b>SHA1</b> <b>SHA-224</b> <b>SHA-256</b> <b>SHA-384</b> <b>SHA-512</b>	Use this field to select MD5 or SHA as the method of password encryption for the specified level of access, or to disable authentication.

Home > SNMP Agent

## SNMP Agent

General    SNMPv3 Account    **SNMPv3 Account Protection**

Disable SNMPv3 account if authentication failed

Max. Authentication Failures  
5

Enable timeout for authentication failure

Each Authentication Failure Timeout (min)  
10

Account Disabled Time Interval (min)  
10

**SAVE**

Parameters	Value	Description
<b>Max Authentication Failure</b>	1 to 10 (default 5)	Specifies a maximum number for authentication failures. If this number is exceeded, the MGate will disable SNMPv3.
<b>Each Authentication Failure Timeout (min)</b>	1 to 1440 (default 10)	Specifies a timeout period when enabling the <b>Timeout for authentication failure</b> function
<b>Account Disabled Time Interval (min)</b>	1 to 60 (default 10)	When the number of authentication failures exceeds the value set in <b>Max Authentication Failure Times</b> , the MGate will disable the SNMPv3 for Account Disabled Time Interval.

## System Settings—SNMP Settings—SNMP Trap

SNMP Trap

Home > SNMP Trap

General    **SNMP Trap Server**

Trap Service

Active     Inactive

**SAVE**

SNMP Trap

Home > SNMP Trap

General    **SNMP Trap Server**

+ CREATE  
maximum number of trap server is 2

Server IP	Port	Trap Version	Community	Account Name	Authentication Type	Privacy Type	
192.168.3.4	4442	Disable	-	-	-	-	

Create Trap Server

**General Setting**

Server IP

Port

**Trap Method**

Trap Version  
 Disable ▼

Parameters	Description
<b>Server IP</b>	SNMP server IP address or domain name; the maximum number of trap servers is 2
<b>Port</b>	SNMP server IP Port.
<b>Trap Version</b>	<b>Disable</b> <b>SNMPv1</b> <b>SNMPv2</b> <b>SNMPv3</b>

# Protocol Settings

## Protocol Settings—Modbus Client Settings

You can manage Modbus devices and their Modbus command tables on this page.

Modbus Master

Home > Modbus Master

Protocol Name

---

Modbus TCP

2 Device, 3 Command


---

Modbus RTU/ASCII

3 Device, 5 Command


Editing

The MGate supports csv file import/export for Modbus settings, it is easy to use when you back up the settings or during installation stage.




Click TCP or the serial port column to set up the Modbus device.

Configure the basic setting for Modbus TCP by clicking the icon next to the Operation Mode: TCP.



Parameter	Value	Default	Description
<b>Initial delay</b>	0 to 30000 ms	0	Some Modbus slaves may take more time to boot up than other devices. In some environments, this may cause the entire system to experience repeated exceptions during the initial boot-up. After booting up, you can force the MGate to wait before sending the first request with the Initial Delay setting.
<b>Maximum Retry</b>	0 to 5	3	This is used to configure how many times the MGate will try to communicate with the Modbus slave when the Modbus command times out.
<b>Response Timeout</b>	10 to 120000 ms	1000	Based on the Modbus standard, the device manufacturer defines the time a slave device takes to respond to a request. A Modbus master can be configured to wait a certain amount of time for a slave's response. If no response is received within the specified time, the master will disregard the request and continue operation. This allows the Modbus system to continue the operation even if a slave device is disconnected or faulty. On the MGate, the Response timeout field is used to configure how long the gateway will wait for a response from a Modbus slave. Refer to your device manufacturer's documentation to manually set the response timeout.


Add the Modbus device by clicking the **ADD DEVICE** button



Editing

GO TO APPLY SETTINGS

### Step 1: Add Modbus device information



CANCEL

NEXT

Parameter	Value	Default	Description
<b>Device Name</b>	Alphanumeric string		Max. 32 characters.
<b>Slave IP</b>	0.0.0.0 to 255.255.255.255	0.0.0.0	The IP address of a remote slave device.
<b>Slave Port</b>	1 to 65535	502	The TCP port number of a remote slave device.
<b>Slave ID</b>	1 to 255	1	The Modbus slave ID.

## Step 2: Add Modbus commands

**Edit Command**

Enable this command

Basic

Command Name  
Voltage

Function  
23 - Read/Write Multiple Registers

Read/Write Multiple Registers

Read Starting Address	Read Quantity
0	10
Write Starting Address	Write Quantity
0	1

Trigger  
Data Change

Endian Swap  
None

Fault Protection  
Keep latest data

Tag  
Tag Type  
raw

CANCEL
DONE

Parameter	Value	Default	Description
<b>Command Name</b>	Alphanumeric string		Max. 32 characters.
<b>Function</b>	<b>1 - Read Coils</b> <b>2 - Read Discrete Inputs</b> <b>3 - Read Holding Registers</b> <b>4 - Read Inputs Registers</b> <b>5 - Write Single Coil</b> <b>6 - Write Single Register</b> <b>15 - Write Multiple Coils</b> <b>16 - Write Multiple Registers</b> <b>23 - Read/Write Multiple Registers</b>		When a message is sent from a Client to a Server device, the function code field tells the server what kind of action to perform.
<b>Trigger</b>	<b>Cyclic</b> <b>Data Change</b> <b>Disable</b>		Disable: The command was never sent Cyclic: The command is sent cyclically at the interval specified in the Poll Interval parameter. Data change: A command is issued when a change in data is detected.
<b>Poll Interval</b> (this will show up when user select trigger mode 'cyclic')	100 to 1200000 ms	1000	Polling intervals are in milliseconds. Since the module sends all requests in turns, the actual polling interval also depends on the number of requests in the queue and their parameters. The range is from 100 to 1,200,000 ms.

Parameter	Value	Default	Description
<b>Endian Swap</b>	None Byte Word Byte and Word	None	Data Byte Swapping None: Don't need to swap Byte: 0x0A, 0x0B, 0x0C, 0x0D becomes 0x0B, 0x0A, 0x0D, 0x0C Word: 0x0A, 0x0B, 0x0C, 0x0D becomes 0x0C, 0x0D, 0x0A, 0x0B. Byte and Word: 0x0A, 0x0B, 0x0C, 0x0D becomes 0x0D, 0x0C, 0x0B, 0x0A.
<b>Read Starting Address</b>	0 to 65535	0	Modbus register address.
<b>Read Quantity</b>	Read Coils: 1 to 2000 Read Discrete Inputs: 1 to 2000 Read Inputs Registers: 1 to 125 Read Holding Registers: 1 to 125 Read/Write Multiple Registers: 1 to 125	10	Specifying how many items to read.
<b>Write Starting Address</b>	0 to 65535	0	Modbus register address.
<b>Write Quantity</b>	Write Multiple Coils: 1 to 1968 Write Multiple Registers: 1 to 123 Read/Write Multiple Registers: 1 to 123	1	Specifying how many items to write into.
<b>Fault Protection</b>	Keep latest data Clear all data bits to 0 Set to user defined value		If the MGate's connection to the other side in a server mode fails, the gateway cannot receive data, but the gateway will continuously send output data to the Modbus device. To avoid problems in this case, the MGate can be configured to react in one of the following three ways: Keep the latest data, clear data to zero, set the data bits to user-defined values.
<b>User-defined Value</b> (This will show up when you select Fault Protection mode as 'Set to user defined value')	00 to FF (Hex)	00 00	The user-defined values to write into the data bits when the Set to user defined value option is selected.
<b>Fault Timeout</b> (This will show up when you select Fault Protection mode as 'Set to user defined value')	1 to 86400 ms	3600	Defines the communication timeout for the opposite side (in a server role).
<b>Tag Type</b>	raw, boolean, int16, int32, int64, uint16, uint32, uint64, float, double, string	raw	Specifying the tag data type. The default is raw for fast multiple data mapping. For other data types, user could also scale the resource data. There are two types: <ul style="list-style-type: none"> <li>Slope-intercept: tag value = (source value * slope) + offset</li> <li>Point-slope: tag value = source value * <math>\left(\frac{\text{target max.} - \text{target min.}}{\text{source max.} - \text{source min.}}\right)</math></li> </ul>

### Step 3: Quick review result, click DONE to finish

< Create New Device

✓ Basic Setting ————— ✓ Command ————— 3 Confirm

Confirm your device settings, and click "DONE" to save your changes. After the device was created, you can edit your device settings any time.

Device Name: Meter

Slave ID: 2

Slave IP: 192.168.10.123

Slave Port: 502

Status: Enable

Number of Commands: 1

< BACK CANCEL **DONE**

It is convenient if you already backed up a frequently used meter profile, just import or export one Modbus device CSV file.

< TCP

Home > Modbus Master > TCP

Operation Mode: TCP ⚙

Search Command Name

Type to search...

**ADD DEVICE** Meter + ADD COMMAND ↓ IMPORT ↓ EXPORT

No.	Command Name	Function	Address, Quantity	Trigger	Poll Interval (ms)	Enable
1	Voltage	3	Read 0, 10	Cyclic	1000	Enable

Editing GO TO APPLY SETTINGS

Follow the same steps for Modbus RTU/ASCII basic settings and devices settings in serial port.

## Serial Basic Settings

Mode

RTU  ASCII

Initial Delay (ms)

0

Max. Retries

3

Response Timeout (ms)

1000

Inter-frame delay automatically determined

The system will automatically determine the delay time of the data frame transmission from the server device to the upstream. You may choose to set the delay time manually by unchecking this option.

Automatically determines the Intercharacter delay

The system will automatically determine the timeout interval between characters for Modbus devices that cannot receive Rx signals within an expected interval. You may choose to set the timeout interval manually by unchecking this option.

CANCEL

DONE

Parameters	Description
Inter-frame delay (only for Modbus RTU)	The system will automatically determine the delay time of the data frame transmission from the server device to the upstream. You may choose to set the delay time manually by unchecking this option, the value range is 10 to 500 ms.
Inter-character timeout (only for Modbus RTU)	The system will automatically determine the timeout interval between characters for Modbus devices that cannot receive Rx signals within an expected interval. You may choose to set the timeout interval manually by unchecking this option, the value range is 10 to 500 ms.

< COM1

Home > Modbus Master > COM1

Operation Mode: ASCII

Search Command Name

Type to search...

ADD DEVICE

meter

+ ADD COMMAND    ↓ IMPORT    ↓ EXPORT

No.	Command Name	Function	Address, Quantity	Trigger	Poll Interval (ms)	Enable
1	power	3	Read 100, 10	Cyclic	1000	Enable
2	voltage	3	Read 100, 10	Cyclic	1000	Enable
3	reset	16	Write 0, 2	Data Change	1000	Enable

meter

meter  
⊗ Disabled  
Slave ID: 2

flow  
⊗ Enable  
Slave ID: 5

temp  
⊗ Enable

Editing

GO TO APPLY SETTINGS

After configuring all Modbus TCP or Modbus RTU/ASCII settings, please remember to click **GO TO APPLY SETTING** and press the **APPLY** button at the bottom right-hand side corner.

**Modbus Master**  
Home > Modbus Master

Protocol Name

★ Modbus Master MANAGE ▾

---

Modbus TCP

TCP  
1 Device, 1 Command

---

Modbus RTU/ASCII

COM1 (ASCII) ⋮  
3 Device, 5 Command

Editing DISCARD APPLY

## Protocol Settings—EtherNet/IP Adapter Settings

You can configure the EtherNet/IP adapter setting on this page.

**EtherNet/IP Adapter**  
Home > EtherNet/IP Adapter

Protocol Name

EtherNet/IP Adapter EDIT  
Encapsulation inactivity timeout: 120

---

EtherNet/IP Adapter

<p><b>Connection1</b></p> <p>Connection point 100 / 110 Data size 200 / 200 Mapping tags 0 / 11</p>	<p><b>Connection2</b></p> <p>Connection point 101 / 111 Data size 0 / 496 Mapping tags 0 / 2</p>	<p><b>Connection3</b></p> <p>Connection point 102 / 112 Data size 0 / 0 Mapping tags 0 / 0</p>	<p><b>Connection4</b></p> <p>Connection point 103 / 113 Data size 0 / 0 Mapping tags 0 / 0</p>
---	--	--	--

Click **EDIT** to adjust the EtherNet/IP basic settings.

Protocol Name

EtherNet/IP Adapter EDIT  
Encapsulation inactivity timeout: 120

### Adapter Common Settings

Encapsulation inactivity timeout (sec)

120

CANCEL

SAVE

Parameter	Value	Default	Description
<b>Encapsulation inactivity timeout (sec)</b>	0 to 3600, (0 for disable)	120	Unit: second If there is no data exchange in for a while, the Ethernet/IP connection will be disconnected.

Click on the Connection button to add O -T and T-O data.

< Connection1 ▾  
Home > EtherNet/IP Adapter > Connection1

Connection1 EDIT

O → T connection point: 100  
T → O connection point: 110  
O → T (Output) data size: 200  
T → O (Input) data size: 200

Data Mapping (O → T) ADD TAGS  
Data size should be below 200 bytes

No.	Tag name	Data type	Byte offset	Quantity (bytes)	Bit offset
No Data					

Data Mapping (T → O) ADD TAGS  
Data size should be below 200 bytes

No.	Tag name	Data type	Byte offset	Quantity (bytes)	Bit offset
No Data					

GO TO APPLY SETTINGS SAVE

Click **EDIT** in the connection column to adjust the connection parameters

## Assembly Instance Settings

Name

Connection1

O → T connection point

100

T → O connection point

110

O → T (Output) data size (bytes)

200

T → O (Input) data size (bytes)

200

CANCEL

SAVE

Parameter	Value	Default	Description
<b>Name</b>		Connection[x]	Name for connection. For example, Connection1
<b>O-&gt;T connection point</b>	1 to 2147483647	100	EtherNet/IP connection instance
<b>T-&gt;O connection point</b>	1 to 2147483647	110	EtherNet/IP connection instance
<b>O-&gt;T (Output) data size (bytes)</b>	0 to 496	0	Unit: byte O->T: Originator to Target
<b>T-&gt;O (Input) data size (bytes)</b>	0 to 496	0	Unit: byte T->O: Target to Originator

Add Tags for O->T and T-O. Notice that the tags must be created in Modbus Client. Click **DONE** on finishing the selection. The selection sequence will also decide the sequence in the EtherNet/IP data frame

### Add Tags

MODBUS\_TCP\_SERVER\_DATA\_MAPPING\_ADD\_TAG\_INFO: MODBUS\_TCP\_SERVER\_DATA\_MAPPING\_ADD\_TAG\_INFO

MODBUS\_TCP\_SERVER\_DATA\_MAPPING\_ADD\_FIELD\_PROVIDERS  
modbus\_serial\_master, modbus\_tcp\_master

5 MODBUS\_TCP\_SERVER\_DATA\_MAPPING\_TAGS

MODBUS TCP SERVER DATA MAPPING ADD FIELD SELECTED TAGS

Search

SELECT ALL CLEAR

[modbus\_serial\_master] flow

status

[modbus\_serial\_master] temp

Total: 5 Selected: 5

DONE

The selected tags will display in the data mapping column by default with byte offset. You may adjust the offset in the EtherNet/IP IO data frame manually.

Data Mapping (T → O) ADD TAGS

Data size should below 200 bytes

No.	Tag name	Data type	Byte offset	Quantity (bytes)	Bit offset
1	modbus_serial_master/flow/status	int32	0	4	0
2	modbus_serial_master/temp/cur	raw	4	20	0
3	modbus_serial_master/temp/status	int32	24	4	0

# Diagnostics

## Diagnostics—Protocol Diagnostics

### Diagnostics—Protocol Diagnostics—Modbus RTU/ASCII Diagnostic

The MGate provides status information for Modbus RTU/ASCII/TCP, EtherNet/IP troubleshooting. Verify data or packet counters to make sure the communications are running smoothly.

#### Modbus RTU/ASCII Diagnostics

[Home](#) > [Modbus RTU/ASCII Diagnostics](#)

Auto refresh

---

#### Modbus

Role	Master
Sent requests	519613
Received valid responses	0
Received invalid responses	0
Received CRC/LRC errors	0
Received exceptions	0
Timeout	519612

---

#### Serial port

# 0	Port number	0
	Break	0
	Frame error	0
	Parity Error	0
	Overrun Error	0
	Mode	ASCII
	Sent requests	519613
	Received valid responses	0
	Received invalid responses	0
	Received CRC/LRC errors	0
	Received exceptions	0
	Timeout	519612

## Diagnostics—Protocol Diagnostics-Modbus TCP Diagnostics

**Modbus TCP Diagnostic**  
Home > Modbus TCP Diagnostics

Auto refresh

**Modbus**

Mode	Master
Number of connections	0
Sent requests	0
Received valid response	0
Received invalid response	0
Received exceptions	0
Timeout	0

**Connections**

No data

## Diagnostics—Protocol Diagnostics-EtherNet/IP Diagnostics

**EtherNet/IP Adapter Diagnostics**  
Home > EtherNet/IP Diagnostics

Auto refresh

**Overview**

Current TCP connections	0
Maximum TCP connections observed	0
Current I/O connections	0
Total TCP transmit packets	0
Total TCP receive packets	0
Total TCP receive invalid packets	0
Total UDP transmit packets	0
Total UDP receive packets	0
Total UDP receive invalid packets	0

**Connections**

No data

# Diagnostics—Protocol Traffic

## Diagnostics—Protocol Traffic-Modbus RTU/ASCII Traffic

To troubleshoot efficiently, the MGate provides a traffic monitoring function that can capture communication traffic for all protocols. These logs present the data in an intelligent, easy-to-understand format with clearly designated fields, including source, destination, function code, and data. Save the complete log in a file by clicking EXPORT csv file.

Modbus RTU/ASCII Traffic

Home > Modbus RTU/ASCII Traffic

Auto Scroll

**START** **STOP** **EXPORT** Ready to capture

No.	Time	Role	Send/Receive	Port	Data Type	Slave ID	Function Code	Data
1	2022-07-04T18:54:23.263+08:00	Master	Resend	1	ASCII	23	3	3A 31 37 30 33 30 30 33 37 30 30 41 41 35 0D 0A
2	2022-07-04T18:54:24.268+08:00	Master	Request	1	ASCII	23	3	3A 31 37 30 33 30 30 33 37 30 30 41 41 35 0D 0A

## Diagnostics—Protocol Traffic-Modbus TCP Traffic

Modbus TCP Traffic Log

Home > Modbus TCP Traffic

Auto Scroll

**START** **STOP** **EXPORT** Ready to capture.

No.	Time	Role	Send/Receive	Remote IP:Port	Slave ID	Function Code	Data
No Data							

# Diagnostics—Event Log

## Diagnostics—Event Log-Log View

You can review and export all event information in the event log.

Event Log

Home > Event Log

**EXPORT** **CLEAR** **REFRESH**

ID	Severity	Category	Event Name	Source	Message	Timestamp
1	Information	Security	Login success	admin 10.122.8.171	Account 'admin' login successfully	2022-07-08T09:33:32.627+08:00
2	Warning	Security	Clear event log	admin 10.122.8.171	Clear event log	2022-07-08T09:33:18.867+08:00

Items per page: 10 1-2 of 2 < 1 /1 >

## Diagnostics—Event Log-Policy Settings

The event policy settings enable the MGate to record important events, which can be recorded in the Remote Log to Syslog server and Local Log, which will be stored with up to 10,000 events in the MGate.

The MGate can also send email alerts, SNMP Trap messages, or open/close the circuit of the relay output when a selected event was triggered.

You can filter events for easy reading or expand by clicking the category, such as System. Tick or untick the events if you want to log it and select which channels you want to use by clicking the channel name. After changing the settings, please remember to SAVE it.

The screenshot shows the 'Event Policy Setting' page. Under 'Channels', four options are listed: Local Log, Remote Log, SNMP Trap, and Email, each with a 'Configured' status and an edit icon. Under 'Events', there are four categories: System, Network, Security, and Maintenance. The 'System' category is expanded, showing four events: 'System start' (Information), 'User trigger reboot' (Warning), 'Power input failure' (Alert), and 'NTP update fail' (Warning). Each event has checkboxes for 'Local log' and 'Remote log', and buttons for 'SNMP trap', 'Email', and 'Relay'.

Event Group	Description
<b>System</b>	Start system, User trigger reboot, Power input failure, NTP update failure
<b>Network</b>	IP conflict, DHCP get IP/renew, IP changed, Ethernet link down
<b>Security</b>	Clear event log, Login success, Login failure, Account/group changed, Password reached lifetime, SSL certificate import, Syslog certificate import
<b>Maintenance</b>	Firmware upgrade success, Firmware upgrade failure, Configuration import success, Configuration import failure, Configuration export, Configuration changed, Load factory default
<b>Modbus</b>	Server connected, Server disconnected, Command recovered, Command fail
<b>EtherNet/IP</b>	Adapter connected; Adapter disconnected

## Local Log Settings

### Local Log Setting

Event Log Overwrite Policy

- Overwrite the Oldest Event Log  
 Stop Recording Event Log

Log Capacity Warning

Capacity Threshold (%)

80

Warning By

SNMP Trap  Email

CANCEL

SAVE

Local Log Settings	Description
<b>Event Log Overwrite Policy</b>	Overwrites the oldest event log Stops recording event log
<b>Log Capacity Warning</b>	When the log amount exceeds the warning
<b>Warning By</b>	SNMP Trap Email

## Remote Log Settings

### Remote Log Setting

Syslog Server 1

Enable

TLS Authentication  
 Enable

IP Address Port

\_\_\_\_\_ 514

Syslog Server 2

Enable

TLS Authentication  
 Enable

IP Address Port

----- 514

CANCEL

SAVE

TLS Authentication

UPLOAD

Common Name	Start Time	Expire Time
No Data		

Client Certificate  
 未選擇任何檔案

Client KEY  
 未選擇任何檔案

CA Certificate  
 未選擇任何檔案

Remote Log Settings	Description
Syslog Server IP	IP address of a server that will record the log data
Syslog Server port	514
<b>TLS Authentication</b>	Enable TLS authentication. Notice TLS files must be uploaded for a successful connection.

## SNMP Trap Settings

SNMP Trap Server

Trap Service

Active  Inactive

For advanced settings, please go to [SNMP Trap Server](#) page

CANCEL **SAVE**

## Email Settings

Email Setting

SMTP Service

Active

Primary Server

Mail Server (SMTP)	Port
10.123.7.18	25

Security Connection

None

Require Authentication

Username

\_\_\_\_\_

Password

\_\_\_\_\_

From (Email address)

test@moxa.com

To (Email address, separated by semicolon)

user@moxa.com

CANCEL **SAVE**

Parameters	Description
<b>Mail Server (SMTP)</b>	The mail server's domain name or IP address.
<b>Port</b>	The mail server's IP port.
<b>Security Connection</b>	TLS STARTTLS STARTTLS-None None
<b>Username</b>	This field is for your mail server's username, if required.
<b>Password</b>	This field is for your mail server's password, if required.
<b>From (Email address)</b>	Email address from which automatic email warnings will be sent.



## Diagnostics—Network Connections

You can see network-related information, including protocol, address, and state.

Network Connections

Home > Network Connections

Auto refresh

Protocol	Recv-Q	Send-Q	Local Address	Foreign Address	State
TCP	0	0	*:80	*:0	LISTEN
TCP	0	0	*:44818	*:0	LISTEN
TCP	0	0	*:22	*:0	LISTEN
TCP	0	0	*:443	*:0	LISTEN
TCP	34	0	10.123.4.44:35032	10.123.7.18:25	CLOSE_WAIT
TCP	0	0	10.123.4.44:443	10.122.8.171:53876	TIME_WAIT
TCP	0	255	10.123.4.44:443	10.122.8.171:53880	ESTABLISHED

## Diagnostics—Ping

This network testing function is available only in the web console. The MGate gateway will send an ICMP packet through the network to a specified host, and the result can be viewed on the web console immediately.

Ping

Home > Ping

Ping Destination

192.168.127.2

---

**ACTIVATE**

## Diagnostics—LLDP

You can see LLDP related information, including Port, Neighbor ID, Neighbor Port, Neigh Port Description, and Neighbor System. Also, you can adjust the transmit interval for LLDP by clicking the **EDIT** button.

LLDP  
Home > LLDP

LLDP Configuration

LLDP Service (Disabled)  
Message Transmit Interval: 30 seconds EDIT

LLDP Table

Interface	Neighbor ID	Neighbor Port	Neighbor Port Description	Neighbor System
No Data				

REFRESH

### LLDP Configuration

LLDP Service

Enable  Disabled

Note: enable/disable this service through [Service Enablement](#)

Message Transmit interval (sec)


30

CANCEL SAVE


# Security

## Security—Account Management

### Security—Account Management—Accounts



Only Administrator group can create or edit accounts for user management. Click **CREATE** to add new accounts. Click the dot icon to edit the account.



Parameters	Value	Description
<b>Group</b>	Administrator, Operator, Guest	Users can change the password for different accounts. The MGate provides three build-in account groups, administrator, operator and guest. Administrator account can access all settings. Operator accounts can access most settings, except security categories. Guest account can only view the overview page. You can create your own group for account management.

## Security—Account Management—Groups

The screenshot shows a web interface for managing groups. At the top, it says "Groups" and "Home > Groups". There is a "+ CREATE" button in the top right corner. Below this is a table listing three built-in groups:

Group		
<b>Administrator (built-in)</b> This group is designed for the supervisor of the device. The accounts of this group will have full privileges. This is a built-in group and cannot be modified or deleted.	8 accounts	⋮
<b>Operator (built-in)</b> This group is designed for the maintainer of the device. The accounts of this group can modify and monitor most of the settings and troubleshooting functions.	0 accounts	⋮
<b>Guest (built-in)</b> This group is designed for the guest/visitor of the device. The accounts of this group can only monitor the status of the device.	1 accounts	⋮

Three MGate built-in types of groups are shown; you can also create your own group by clicking **CREATE**.

The screenshot shows a "Create New Group" form. It has a vertical scrollbar on the right side. The form is divided into several sections:

- Basic Information**
  - Name:
  - Description - optional:
- Access Permissions**
  - System Configuration: Read write (dropdown arrow)
- Protocol Setting**
  - Read write (dropdown arrow)
- Diagnostic**
  - Read write (dropdown arrow)
- Security**
  - No display (dropdown arrow)
- Maintenance**
  - Read write (dropdown arrow)
- Restart**
  - Read write (dropdown arrow)

At the bottom of the form, there are two buttons: "CANCEL" and "SAVE".

Parameters	Value	Description
<b>Basic Information</b>		Includes Name and Description for the new Group.
<b>Access Permissions</b>	No display	Corresponding to the configuration menu on the left-hand side of the web console, you can select different permissions for a new group. Displays will not show the page on the right-hand side menu.
	Read only	
	Read write	

## Security—Account Management—Password Policy

### Password Policy

[Home](#) > Password Policy

#### Password Strength Setting

Password Minimum Length  
8

Password Complexity Strength Check

Select all password strength requirements

- At least one digit (0-9)
- Mixed upper and lower case letters (A-Z, a-z)
- At least one special character (~! @\$%^&\* \_+=`\'0000;"" <>.,/?)

#### Password Lifetime Setting

The password lifetime determines how long the password is effective. If password has expired, a popup message and event will notify user to change the password for security reasons.


Enable password lifetime check

Password Lifetime (day)  
90

**SAVE**

Parameter	Value	Description
<b>Password Minimum Length</b>	8 to 128	The minimum password length
<b>Password Complexity Strength Check</b>		Select how the MGate checks the password's strength
<b>Password lifetime Setting</b>	90 to 180 days	Set the password's lifetime period.

# Security—Service



Parameter	Value	Description
<b>HTTP Service</b>	Enable/Disable	To enhance security, all HTTP requests will redirect to HTTPS when the HTTP service is enabled. You can also disable the HTTP service.
<b>HTTPS Service</b>	Enable/Disable	Disabling this service will disable the web console and search utility connections, thus cutting off access to the configuration settings. To re-enable the HTTPS communication, reset to the factory default settings via the hardware Reset button.
<b>Ping Service</b>	Enable/Disable	Disabling this service will block ping requests from other devices.
<b>SD Card</b>	Enable/Disable	Disabling this service will deactivate the SD card function for backup and restore configuration files.
<b>SNMP Agent Service</b>	Enable/Disable	Enable or disable SNMP agent function.
<b>LLDP Service</b>	Enable/Disable	Enable or disable LLDP function.
<b>Reset button disable after 60 sec</b>	Always enable and disable after 60 sec.	The MGate provides a Reset button to load factory default settings. For enhanced security, users can disable this function. In the disabled mode, the MGate will still enable the Reset button for 60 seconds after bootup, just in case you really need to reset the device.

## Security—Allow List

These settings are used to restrict access to the MGate by the IP address. Only IP addresses on the list will be allowed to access the device. Notice the restriction includes configuration and protocol conversion.

### Allow List

[Home](#) > [Allow List](#)

Activate the accessible IP list (All communications are NOT allowed for the IPs NOT on the list)

No.	Active	IP	Netmask
1	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
2	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
3	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
4	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
5	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>

## Security—DoS Defense

Users can select from several options to enable DoS Defense in order to fend off cybersecurity attacks. A denial-of-service (DoS) attack is an attempt to make a machine or a network resource unavailable. Users can select from the following options to counter DoS attacks.

### DoS Defense

[Home](#) > DoS Defense

#### Configuration

Null Scan	<input type="checkbox"/>
NMAP-Xmax Scan	<input type="checkbox"/>
SYN/FIN Scan	<input type="checkbox"/>
FIN Scan	<input type="checkbox"/>
NMAP-ID Scan	<input type="checkbox"/>

#### SYN-Flood

Enable	<input type="checkbox"/>
Limit	<input type="text" value="4000"/> pkt/s

#### ICMP-Death

Enable	<input type="checkbox"/>
Limit	<input type="text" value="4000"/> pkt/s

**SAVE**

# Security—Login Policy

## Login Message

You can input a message for Login or for Login authentication failure messages.

The screenshot shows the 'Login Policy' configuration page with the 'Login Message' tab selected. It contains two text input fields. The first is labeled 'Login Message - optional' and contains the text 'Hello'. The second is labeled 'Login Authentication Failure Message' and contains the text 'The account or password you entered is incorrect.(Your account will be temporarily locked if excessive tried.)'. Both fields have a character count indicator (5 / 256 and 110 / 256 respectively) and a 'SAVE' button at the bottom.

## Login Lockout

The screenshot shows the 'Login Policy' configuration page with the 'Login Lockout' tab selected. It features several settings: an unchecked checkbox for 'Enable Login Failure Lockout', a 'Max Failure Retry Times' field set to 5, an unchecked checkbox for 'Reset the Login Failure Counter' with a sub-note, a 'Reset Period (min)' field set to 10, and a 'Lockout Time (min)' field set to 10. A 'SAVE' button is located at the bottom.

Parameter	Value	Description
<b>Max Failure Retry Times</b>	1 to 10 (default 5)	You can specify the maximum number of failures retries, if exceed the retry times, MGate will lock out for that account login
<b>Reset Period (min)</b>	1 to 1440 (default 10)	You can specify the reset period time when enabling the "reset the login failure counter" function
<b>Lockout Time(min)</b>	1 to 60 (default 10)	When the number of login failures exceeds the threshold, the MGate will lock out for a period.

## Login Session

### Login Policy

Home > Login Policy

Login Message   Login Lockout   **Login Session**

---

Maximum login user for HTTP+HTTPS  
5

---

Auto logout setting (min)  
1440

---

**SAVE**

Parameter	Value	Description
<b>Maximum login users for HTTP+HTTPS</b>	1 to 10 (default 5)	The number of users that can access the MGate at the same time.
<b>Auto logout setting (min)</b>	1 to 1440 (default 1440)	Sets the auto logout time period.

## Security—Certificate Management

Use this function to load the Ethernet SSL certificate. You can import or delete SSL certificate/key files. This function is only available for the web console.

### Certificate Management

Home > Certificate Management

Configuration

---

Issue to                      10.123.4.44  
Issue by                        Moxa Inc.  
Valid                            from 2022-6-2 to 2027-6-1

---

SSL

---

Select SSL Certificate      **IMPORT**

Delete SSL Certificate      **DELETE**

# Maintenance

## Maintenance—Configuration Import/Export

There are three main reasons for using the Import and Export functions:

- Applying the same configuration to multiple units. The Import/Export configuration function is a convenient way to apply the same settings to units in different sites. You can export the configuration as a file and then import the configuration file onto other units.
- Backing up configurations for system recovery. The export function allows you to export configuration files that can be imported onto other gateways to restore malfunctioning systems within minutes.

Troubleshooting. Exported configuration files help administrators to identify system problems that provide useful information for Moxa's Technical Service Team when maintenance visits are requested.

For cybersecurity reason, you can export configuration file with an authentication key, length from 8 to 16 characters. If the key to the imported configuration file differs from the key to the exported file, the import process will fail.

The screenshot shows the 'Configuration Import/Export' web console interface. The title is 'Configuration Import/Export' with a breadcrumb 'Home > Configuration Import/Export'. There are two tabs: 'Configuration' (active) and 'File Authentication'. Under the 'Configuration' tab, there are two main sections: 'Backup configuration' with a green 'BACKUP' button, and 'Restore configuration' with a checkbox for 'Update network settings' and a file selection area. The file selection area shows '選擇檔案' (Select file) and '未選擇任何檔案' (No file selected). Below the file selection area is a light blue 'RESTORE' button.

The screenshot shows the 'Configuration Import/Export' web console interface with the 'File Authentication' tab active. The title is 'Configuration Import/Export' with a breadcrumb 'Home > Configuration Import/Export'. There are two tabs: 'Configuration' and 'File Authentication' (active). Under the 'File Authentication' tab, there is a 'File authentication' section with two radio buttons: 'Enable' (selected) and 'Disabled'. Below this is a 'File authentication key' input field with a toggle icon (an eye) to its right. At the bottom left of the form is a light blue 'SAVE' button.

## Maintenance—Firmware Upgrade

Firmware updates for the MGate are available on the Moxa website. After you have downloaded the new firmware onto your PC, you can use the web console to write it onto your MGate. Select the desired unit from the list in the web console and click **Submit** to begin the process.




### ATTENTION

DO NOT turn off the MGate power before the firmware upgrade process is completed. The MGate will erase the old firmware to make room for the new firmware to flash memory. If you power off the MGate and end the progress, the flash memory will contain corrupted firmware, and the MGate will fail to boot. If this happens, contact Moxa RMA services.



## Maintenance—Load Factory Default

To clear all the settings on the unit, use the Load Factory Default to reset the unit to its initial factory default values.



### ATTENTION

Load Default will completely reset the configuration of the unit, and all the parameters you have saved will be discarded. Do not use this function unless you are sure you want to completely reset your unit.


## Restart

You can reboot the MGate by clicking the RESTART button.



### ATTENTION

Unsaved configuration files will be discarded during a reboot.



# Status Monitoring

The Status Monitoring function provides status information of field devices when the MGate is being used as a Modbus client. If a Modbus device fails or a cable comes loose, the gateway will not be able to receive up-to-date data from the Modbus device. The out-of-date data will be stored in the gateway's memory and will be retrieved by the client (e.g., PLC), which is not aware that the slave device is not providing up-to-date data. To handle this situation, the MGate provides a warning mechanism to report the list of slave devices that are still "alive" through the Status Monitoring function.

The MGate will create a status tag when a Modbus device is created. This shows if the Modbus device connection is valid or invalid. However, these tags cannot be added to the EtherNet/IP mapping of a client (e.g., PLC) to get the alive status of the Modbus devices.

## ADD TAGS

**Info:**  
Select one or more tag providers to get their tags, and select tags to map data.

Providers

modbus\_serial\_master



2 Tags

Selected Tags

Search

SELECT ALL

CLEAR

[modbus\_serial\_master] d1

c1

status

Total: 2 Selected: 1

DONE

The highest significant bit shows the status. 1 is invalid, 0 is valid.

Provider	Source	Name	Type	Value	Timestamp
modbus_tcp_master	Meter1	status	int32	valid (0x0000)	2022-08-01T10:41:10.542+08:00

Provider	Source	Name	Type	Value	Timestamp
modbus_tcp_master	Meter1	status	int32	invalid (0x80000000)	2022-08-01T10:46:31.403+08:00

## 4. Network Management Tool (MXstudio)

---

Moxa's MXstudio industrial network management suite includes tools such as MXconfig, MXview and N-Snap. MXconfig is for industrial network configuration; MXview is for industrial management software; and N-Snap is for industrial network snapshot. The MXstudio suite in the MGate includes MXconfig and MXview, which are used for the mass configuration of network devices and monitoring network topology, respectively. The following functions are supported:

Tool	Function Support
MXconfig	<ol style="list-style-type: none"><li>1. System name and login password modification</li><li>2. Network settings</li><li>3. Configuration import/export</li><li>4. Firmware upgrade</li></ol>
MXview	<ol style="list-style-type: none"><li>1. Configuration import/export</li><li>2. LLDP for topology analysis</li><li>3. Security View**</li></ol>

\*\*Security View can check the security level of devices under the IEC62443-4-2 standard.

# A. SNMP Agents with MIB II and RS-232-Like Groups

The MGate has built-in Simple Network Management Protocol (SNMP) agent software that supports SNMP Trap, RFC1317 and RS-232-like groups, and RFC 1213 MIB-II.

## RFC1213 MIB-II Supported SNMP Variables

System MIB	Interfaces MIB	IP MIB	ICMP MIB
sysDescr	ifNumber	ipForwarding	icmpInMsgs
sysObjectID	ifIndex	ipDefaultTTL	icmpInErrors
sysUpTime	ifDescr	ipInReceives	icmpInDestUnreachs
sysContact	ifType	ipInHdrErrors	icmpInTimeExcds
sysName	ifMtu	ipInAddrErrors	icmpInParmProbs
sysLocation	ifSpeed	ipForwDatagrams	icmpInSrcQuenchs
sysServices	ifPhysAddress	ipInUnknownProtos	icmpInRedirects
	ifAdminStatus	ipInDiscards	icmpInEchos
	ifOperStatus	ipInDelivers	icmpInEchoReps
	ifLastChange	ipOutRequests	icmpInTimestamps
	ifInOctets	ipOutDiscards	icmpTimestampReps
	ifInUcastPkts	ipOutNoRoutes	icmpInAddrMasks
	ifInNUcastPkts	ipReasmTimeout	icmpInAddrMaskReps
	ifInDiscards	ipReasmReqds	icmpOutMsgs
	ifInErrors	ipReasmOKs	icmpOutErrors
	ifInUnknownProtos	ipReasmFails	icmpOutDestUnreachs
	ifOutOctets	ipFragOKs	icmpOutTimeExcds
	ifOutUcastPkts	ipFragFails	icmpOutParmProbs
	ifOutNUcastPkts	ipFragCreates	icmpOutSrcQuenchs
	ifOutDiscards	ipAdEntAddr	icmpOutRedirects
	ifOutErrors	ipAdEntIfIndex	icmpOutEchos
	ifOutQLen	ipAdEntNetMask	icmpOutEchoReps
	ifSpecific	ipAdEntBcastAddr	icmpOutTimestamps
		ipAdEntReasmMaxSize	icmpOutTimestampReps
		ipRouteDest	icmpOutAddrMasks
		ipRouteIfIndex	icmpOutAddrMaskReps
		ipRouteMetric1	
		ipRouteMetric2	
		ipRouteMetric3	
		ipRouteMetric4	
		ipRouteNextHop	
		ipRouteType	
		ipRouteProto	
		ipRouteAge	
		ipRouteMask	
		ipRouteMetric5	
		ipRouteInfo	
		ipNetToMediaIfIndex	
		ipNetToMediaPhysAddress	
		ipNetToMediaNetAddress	
		ipNetToMediaType	
		ipRoutingDiscards	

Address Translation MIB	TCP MIB	UDP MIB	SNMP MIB
atIfIndex	tcpRtoAlgorithm	udpInDatagrams	snmpInPkts
atPhysAddress	tcpRtoMin	udpNoPorts	snmpOutPkts
atNetAddress	tcpRtoMax	udpInErrors	snmpInBadVersions
	tcpMaxConn	udpOutDatagrams	snmpInBadCommunityNames
	tcpActiveOpens	udpLocalAddress	snmpInBadCommunityUses
	tcpPassiveOpens	udpLocalPort	snmpInASNParseErrs
	tcpAttemptFails		snmpInTooBigs
	tcpEstabResets		snmpInNoSuchNames
	tcpCurrEstab		snmpInBadValues
	tcpInSegs		snmpInReadOnlys
	tcpOutSegs		snmpInGenErrs
	tcpRetransSegs		snmpInTotalReqVars
	tcpConnState		snmpInTotalSetVars
	tcpConnLocalAddress		snmpInGetRequests
	tcpConnLocalPort		snmpInGetNexts
	tcpConnRemAddress		snmpInSetRequests
	tcpConnRemPort		snmpInGetResponses
	tcpInErrs		snmpInTraps
	tcpOutRsts		snmpOutTooBigs
			snmpOutNoSuchNames
			snmpOutBadValues
			snmpOutGenErrs
			snmpOutGetRequests
			snmpOutGetNexts
			snmpOutSetRequests
			snmpOutGetResponses
			snmpOutTraps
			snmpEnableAuthenTraps
			snmpSilentDrops
			snmpProxyDrops

## RFC1317 RS-232-Like Groups

RS-232 MIB	Async Port MIB
rs232Number	rs232AsyncPortIndex
rs232PortIndex	rs232AsyncPortBits
rs232PortType	rs232AsyncPortStopBits
rs232PortInSigNumber	rs232AsyncPortParity
rs232PortOutSigNumber	
rs232PortInSpeed	
rs232PortOutSpeed	

Input Signal MIB	Output Signal MIB
rs232InSigPortIndex	rs232OutSigPortIndex
rs232InSigName	rs232OutSigName
rs232InSigState	rs232OutSigState