# IMC-P21A-G2 Series Quick Installation Guide

# **Moxa Industrial Media Converter**

Version 1.1, August 2024

Technical Support Contact Information www.moxa.com/support



P/N: 1802000210122

#### Overview

The IMC-P21A-G2 Series comprises PoE+ Fast Ethernet-to-fiber media converters. It provides Ethernet media conversion from 10/100 Base-T(X) to 100 Base-FX (SC/ST connectors).

Classified as power source equipment (PSE), the IMC-P21A-G2 Series media converters can provide up to 36 watts of power to powered devices (PD).

The IMC-P21A-G2 Series can power IEEE 802.3at compliant powered devices (PD), eliminating the need for additional wiring. It supports IEEE 802.3/802.3u/802.3x with 10/100M and MDI/MDI-X auto-sensing to provide a total solution for your industrial Ethernet network.

## **Package Checklist**

The following items come with the IMC-P21A-G2 Series when we ship it:

- Moxa PoE+ Fast Ethernet-to-fiber media converters
- Quick installation guide (printed)
- · Warranty card


**NOTE** If any of these items are missing or damaged, please contact your customer service representative for assistance.

## **Features**

- Supports 10/100Base-TX auto-negotiation and auto-MDI/MDI-X
- Multi-mode and single-mode with SC or ST fiber connector available
- Supports Link Fault Pass-through
- Redundant VDC (44 to 57 VDC) power inputs, DIN rail or wall mountable (optional)
- · Operating temperature ranges from -10 to 60°C
- Supports store-and-forward mode and pass-through mode


# Panel Layout of the IMC-P21A-G2 Series

# Front Panel View (IMC-P21A-G2-M-SC)




- Terminal block for power input PWR1/PWR2
- 2. Power input PWR1 LED
- 3. Power input PWR2 LED
- 4. Smart PoE LED indicator of PoE+ port
- 5. Fiber Link/Active LED
- 6. 10/100Mbps copper port LED
- 7. 10/100Mbps IEEE 802.3af/at port
- 8. 100Base-FX (ST/SC connector) Port
- 9. Grounding screw
- 10. DIP switch11. DIN-rail mounting kit

**Top Panel View** 





#### **Rear Panel View**




# Mounting Dimensions (unit = mm)

Unit: mm







Front View Side View Rear View

# **DIN-rail Mounting**


The metal DIN-rail mounting kit in the package is fixed to the back panel of the IMC-P21A-G2 Series. Mount the IMC-P21A-G2 Series on a corrosion-free mounting rail that adheres to the EN 60715 standard.

**NOTE** The length of the screws used for the DIN-rail mount bracket: 6 mm; Ø 3 mm.

## Suggested Installation Method

**STEP 1:** Insert the upper lip of the DIN-rail kit into the mounting rail


**STEP 2:** Press the IMC-P21A-G2 Series towards the mounting rail until it snaps into place.



## Suggested Removal Method

**STEP 1:** Pull down the latch on the DIN-rail kit with a screwdriver.

**STEP 2:** Gently pull the IMC-P21A-G2 Series forward and lift it up to remove it from the mounting rail.



## Wall Mounting (optional)

For some applications, it is convenient to mount the IMC-P21A-G2 Series on the wall, as shown in the following illustrations.


NOTE The length of screws for wall-mount bracket used:

- Equipment side: 6 mm; Ø 3 mm
- Wall side: 10 mm; Ø 3 mm

STEP 1: Remove the aluminum DIN-rail attachment plate from the rear panel of the IMC-P21A-G2 Series, and then attach the wall-mount plates with three M3 screws.

STEP 2: Mounting the IMC-P21A-G2 Series on the wall requires two M3 screws. Use the IMC-P21A-G2 Series with the wall-mount plates attached as a guide to mark the correct location of the two screws.

## Unit: mm (inch)




## **Grounding the IMC-P21A-G2 Series**



Grounding and wire routing help limit the effects of noise due to electromagnetic interference (EMI). Run the ground connection from the ground screw to the grounding surface before connecting the devices.

# Wiring the Power Inputs

The 4-contact terminal block connector on the IMC-P21A-G2's top panel is used for the IMC-P21A-G2's two DC inputs. The top and front views of one of the terminal block connectors are shown here.



**STEP 1:** Use a small flat-blade screwdriver to press a wire locker.

**STEP 2:** Insert a positive/negative DC wire into the V+/V- terminals, respectively.

**STEP 3:** Release the wire locker and check whether the wire is fixed.

Install the input terminal block using 16-28 AWG wires with 8 to 9 mm of the conductor insulation stripped.

## **Redundant Power Inputs**

Both power inputs can be connected simultaneously to live DC power sources. If one power source fails, the other live source acts as a backup, and automatically supplies all the IMC-P21A-G2's power needs.

## **Communication Connections**

#### **RJ45 Ethernet Port Connection**

The IMC-P21A-G2 Series has one 10/100BaseT(X) Ethernet port on the front panel for connecting to Ethernet-enabled devices.

Pinouts and cable wiring diagrams for both MDI (NIC-type) and MDI-X (HUB/switch-type) ports for both straight-through and crossover Ethernet cables are shown below:

 MDI Port Pinouts

 Pin
 Signal

 1
 Tx+

 2
 Tx 


 3
 Rx+

 6
 Rx


MDI-X Port Pinouts		
Pin	Signal	
1	Rx+	
2	Rx-	
3	Tx+	
6	Tx-	



#### Straight-Through Cable Wiring



#### **Crossover Cable Wiring**




# **Fiber Optic Port Connection**


The concept behind the SC/ST port and cable is straightforward. Suppose you are connecting devices I and II. Contrary to electrical signals, optical signals do not require a circuit to transmit data. One of the optical lines is used to transmit data from device I to device II, and the other optical line is used to transmit data from device II to device I, for full-duplex transmission.

All you need to remember is to connect the Tx (transmit) port of device I to the Rx (receive) port of device II, and the Rx (receive) port of device I to the Tx (transmit) port of device II. If you make your own cables, we suggest labeling the two sides of the same line with the same letter (A-to-A and B-to-B, as shown below, or A1-to-A2 and B1-to-B2).

## **SC-Port Pinouts**

## SC-Port to SC-Port Cable Wiring






#### **ST-Port Pinouts**

#### ST-Port to ST-Port Cable Wiring










# **DIP Switch Setting**



Switch No.	Function Name	State	Description		
1	LFPT	On (Default)	Enables link fault pass-through. The link status on the TX port will inform the FX port of the same device and vice versa.		
		Off	Disables link fault pass-through. The link status on the TX port will not inform the FX port.		
2	Operating Mode	On (Default)	Selects store-and-forward mode. It forwards packets to a destination port after receiving the entire packet. The latency depends on the packet length.		
		Off	Selects cut-through mode. Operates with minimum latency. Both transceivers interconnect via internal MIIs, and they do not use the internal switch engine and data buffer.		
	Force TP Speed	On	Forces 100 Mbps on the Ethernet port.		
3		Off (Default)	Auto-negotiation		

Switch No.	Function Name	State	Description	
4	P.R.R. (Power Remote Reset)	On (Default)	Enables PoE; the PoE converter provides power to PD.  Disables PoE; the PoE converter does NO	
		Off	provide power to PD.	
5		On	Enables the P.R.R. function when the fiber port link is down for 3 seconds and the PoE setting is enabled (On status); the PoE converter stops providing power to the PD, which means the PD power will turn OFF.  After 1 second, the PoE converter continues to provide power to the PD, and then the PD power is turned back ON to reset the PD.	
		Off	Disables the PSE reset function; no reset	
		(Default)	PD function.	

# **LED Indicators**

The front panel of the IMC-P21A-G2 contains several LED indicators. The function of each LED is described in the table below.

LED	Color	State	Description		
PWR1	Green	On	Power is being supplied to power input PWR1.		
PWRI		Off	Power is not being supplied to power input PWR1.		
PWR2	Green	On	Power is being supplied to power input PWR2.		
		Off	Power is not being supplied to power input PWR2.		
		On	TP port's 100 Mbps link is active.		
	Green	Blinking Data is being transmitted at 100 Mbp			
1		Off	100BaseTX Port's link is inactive.		
(Ethernet)	Amber	On	TP port's 10 Mbps link is active.		
		Blinking	Data is being transmitted at 10 Mbps.		
		Off TP Port's 10 Mbps link is inactive.			
2		On FX port's 100 Mbps is active.			
(Fiber	Green	Blinking	Data is being transmitted at 100 Mbps.		
Link)		Off	100BaseFX port is inactive.		
	Green	On	The PoE device is connected by the		
			IEEE 802.3at standard.		
		Off	Power is not being supplied to a PD.		
	Amber	On	The PoE device is connected by the		
PoE (PSE			IEEE 802.3af standard.		
Indicator)		Off	Power is not being supplied to a PD.		
	Red	On	PD detects failure.		
		Blinking			
		(4 times/	Overcurrent has occurred on the PD.		
		sec)	D.F. in an analysis of the second sec		
		Off	PoE is operating normally.		

# **Specifications**

Technology						
Standards		IEEE802.3, 802.3u, Link Fault Pass-through (LFPT), IEEE802.3at, IEEE802.3af				
Interface	•					
RJ45 Ports	10/1	00BaseT(X)				
Fiber Ports			connectors av	ailable)		
LED Indicators				,		
Dip Switch	_	Power, Ethernet, Fiber, PoE LFPT, Operating Mode, Force TP Speed, PoE, P.R.R				
Optical Fiber		operating me	20, 10.00 11 0p	2007 : 027 :		
opaicai i ize.		Multi-	·mode	Single-mode		
Distance, km		4	5	40		
Wavelength, nm		1300	1300	1310		
Min. TX Output, dBi	n	-20	-20	-5		
Max. TX Output, dB		-10	-10	0		
	111					
Sensitivity, dBm Recommended Diar	notor	-32	-32	-34		
(Core/Cladding) µm		62.5/125	50/125	9/125		
Power Requireme		7.1/DC dual as				
Input Voltage		7 VDC, dual por	wer inputs			
Input Current		mA max				
Connection	_	vable Termina	l Block			
Overload Current	1.5 A					
Protection						
Reverse Polarity	Prese	ent				
Protection						
<b>Physical Characte</b>						
Casing		with I/O plugs,	SECC case			
Dimensions	_	20.3 x 73 x 90 mm				
Installation		ail, wall mount	ing (optional)			
<b>Environmental Lin</b>						
Operating	Stand	dard Models: -1	.0 to 60°C (32	to 140°F)		
Temperature		,				
Storage	-40 t	-40 to 85°C (-40 to 185°F)				
Temperature						
Ambient Relative	5 to 9	90% (non-cond	ensing)			
Humidity						
Regulatory Appro						
Safety	UL 62	2368				
EMI		CISPR 22, FCC Part 15B Class B				
EMS	IEC 6	1000-4-2 ESD	: Contact: 6 kV	; Air: 8 kV		
	IEC 61000-4-3 RS: 80 MHz to 1 GHz: 10 V/m					
	IEC 61000-4-4 EFT: Power: 2 kV; Signal: 1 kV					
IEC 61000-4-5 Surge: Power: 2 kV; Sigr			; Signal: 1 kV			
	IEC 61000-4-6 CS: Signal: 10 V					
Shock	IEC 60068-2-27					
Freefall	ISTA	ISTA-1A				
Vibration	IEC 6	0068-2-64				
	IEC 6	0068-2-6				
Warranty						
Warranty Period	5 years					
Details	See \	www.moxa.com	/warranty			



## Caution

- This is a Class 1 (IEC 60825:2014) laser/LED product. Do not stare into the laser beam.
  - Caution—Use of the controls or adjustments or the performance of procedures other than those specified herein may cause hazardous radiation exposure.
  - Complies with 21 CFR 1040.10 and1040.11, except for conformance with IEC 60825-1 Ed. 3., as described in Laser Notice No. 56, dated May 8, 2019.
- Before connecting the equipment to DC power inputs, make sure the DC power source voltage is stable
  - The wiring of input terminal block shall be installed by a skilled person.
  - Wire type: Cu
  - Only use 16-24 AWG wire size.
- The product is intended to be supplied by a UL Listed Power Unit is rated 44-57 VDC @ 828 mA min., Tma = 60°C (min.). If you need further help with purchasing the power source, please contact Moxa for further information.
- If using a Class I adapter, the power cord must be connected to a socket-outlet with an earthing connection.
- The product is considered not likely to require a connection to an Ethernet network with outside plant routing.

## NOTE PoE output specification (IEEE802.3af)

44-57 VDC, 94 mA max. (PoE Class 1)

44-57 VDC, 185 mA max. (PoE Class 2)

44-57 VDC, 388 mA max. (PoE Class 3)

44-57 VDC, 750 mA max. (PoE Class 4)

(44-48 VDC, 33 W max.)

(48-57 VDC, 36 W max.)